

## Deplug Method 4FF

This guide will help you snap the SIM out of the card. Follow the instructions below to insert the SIM in your phone.


## Step1:

Take the ISO card.



## Step2:

Put your index finger under the 4FF and your thumb above the 4FF. Push the module from behind with your index finger towards the front.



## Step3:

4FF ready to use.



